


**Studio
London.**

Chorus Large Coffee Table



46.5" W x 34" D x 16" H

Congratulations on your purchase from Studio London!

In buying one of our quality products, you now own an item we sincerely hope you will love for years to come, without it costing the earth.

Responsibility is one of our core brand values. For every item sold, a tree is planted. Additionally, we invest in carbon reducing schemes, ensure all our materials are sustainably and responsibly sourced, and audit our suppliers to ensure they are safe, supportive, and ethically sound.

We hope you love your item. We would love to hear any feedback or comments.


Visit us at www.studiolondon.net to comment or to find out more, and please follow us on Instagram at [studio_london_design](https://www.instagram.com/studio_london_design).

Tools required



Time to assemble
30 mins

People to assemble



Important safety information

Warnings







- ⚠ This product is not suitable for bedrooms.
- ⚠ The product should only be used on firm, level ground.
- ⚠ Keep small parts out of reach of children.
- ⚠ Ensure the product is fully assembled as illustrated before use.

Do's


- ✓ Check the pack and make sure you have all the parts listed.
- ✓ Check all screws or bolts are tightened and inspect regularly.
- ✓ Make sure the legs remain in contact with the ground at all times.

Don't

- ✗ Do not over tighten screws or bolts.
- ✗ Do not stand on the product.
- ✗ Do not use power tools to construct as overtightening and panel failure may occur.




Your Chorus Large Coffee Table



Ref	Description	Dimensions	Qty
1	Table top	44 3/4" x 32" x 3"	1
2	Leg	4 3/4" x 3 1/4" x 15"	4

Fixtures and fittings



Fixtures and fittings
supplied (true to size)

Accessories and fittings supplied (true to size)				mm									
Ref	Description	Dimensions	Qty										
A	Bolt	M10 x 60mm	8										
B	Spring washer	Dia.16mm	8										
C	Washer	Dia.22mm	8										

Fixtures and fittings
supplied (not to scale)

Ref	Description	Dimensions	Qty	
D	Wrench		1	


Product assembly

Chorus Large Coffee Table

Step 1

Parts, fittings and tools

① ②



Find a clear area for assembly, near where you intend to use the table.

Place the table top (1) upside down on a soft surface, being careful not to damage the finish.


Taking legs (2), turn upside down and locate into the table top (1) as shown.

Step 2

Parts, fittings and tools

① ②

A B C D



Insert x 1 bolt (A) x 1 spring washer (B) x 1 washer (C) combine together as shown above and tighten with the wrench (D) provided.




Repeat with each of the four legs (x4)

Product assembly

Chorus Large Coffee Table

Step 3


Parts, fittings and tools



With 2 people carefully place the table on its feet. Take care when lifting not to damage the legs.


Step 4

Parts, fittings and tools



Turn the adjustable feet to allow the table to stand flat on the floor

Product assembly
Chorus Large Coffee Table



Care and maintenance

Wood furniture

Wood displays displays different grain patterns depending on which way they are cut - for example, the 'medullary ray' which can appear on oak furniture is a mark of good quality timber - these are just characteristics of the natural beauty of the wood. Some furniture is also deliberately aged and rustic.

Wood veneers also allow a distinctive pattern to be created on some surfaces, such as tabletops and drawer fronts by the way slivers are arranged.

All timber and veneer surfaces will change colour and mellow over time. New furniture will initially vary in shade from items that have been previously purchased.

How to care for your wood furniture

Furniture with a hard lacquer, wax polish or painted surface should be dusted with a dry cloth.

Waxed furniture will need to be given a coat of beeswax a couple of times a year to help maintain its lustre.

Spray polishes are best avoided as they contain silicones which may spoil the furniture's surface when building up over time.

Make sure all surfaces are protected from the heat and liquids by mats and coasters. Wipe up spills immediately and ensure that a mat or pad is placed under paper if you are writing.

Our furniture will endure most temperatures in the home, but it is best to avoid placing furniture next to heat sources such as radiators or fires. Be particularly careful with solid wood as the lack of humidity caused by home heating can cause damage such as warping.

Caution

This wood has a painted surface that can scratch. Please avoid contact with hard, sharp objects. Avoid placing plant pots or vases without waterproof mats to prolong the life of the product.

Please do not sit or lean on this product.

Maximum Load Capacity: 110 lbs for the top surface

Retain these instructions for future reference.

Your feedback is very important to us and we would love to hear your comments on you new furniture. Please visit our website to leave a review. Thank you.