


**Studio
London.**

Mirren Sideboard 160cm
Assembly instructions



62.9"W x 19.3"D x 29.5"H


Congratulations on your purchase from Studio London!

In buying one of our quality products, you now own an item we sincerely hope you will love for years to come, without it costing the earth.

Responsibility is one of our core brand values. For every item sold, a tree is planted. Additionally, we invest in carbon reducing schemes, ensure all our materials are sustainably and responsibly sourced, and audit our suppliers to ensure they are safe, supportive, and ethically sound.

We hope you love your item. We would love to hear any feedback or comments.

Visit us at www.studiolondon.net to comment or to find out more, and please follow us on Instagram at [studio_london_design](https://www.instagram.com/studio_london_design).



Important safety information

Warnings







- ⚠ **This product is not suitable for bedrooms.**
- ⚠ The product should only be used on firm, level ground.
- ⚠ Keep small parts out of reach of children.
- ⚠ Ensure the product is fully assembled as illustrated before use.

Do's


- ✓ Check the pack and make sure you have all the parts listed.
- ✓ Check all screws or bolts are tightened and inspect regularly.
- ✓ Make sure the legs remain in contact with the ground at all times.

Don't

- ✗ Do not over tighten screws or bolts.
- ✗ Do not stand on the product.
- ✗ Do not use power tools to construct as overtightening and panel failure may occur.




Your sideboard



Ref	Description	Dimensions	Qty
①	Cabinet	62.9" x 19.3" x 25.6"	1
②	Leg	16.5" x 5.9" x 1.9"	2

Fixtures and fittings



Fixtures and fittings
supplied (actual size)

Ref	Description	Dimensions	Qty	mm 0 10 20 30 40 50 60 70
A	Large allen bolt	M6 x 45mm	8	
B	Small allen bolt	M6 x 15mm	2	
C	Washer	Dia.19mm	2	

Fixtures and fittings
supplied (not actual size)



Ref	Description	Dimensions	Qty	
D	Allen key	#4	1	
E	Wall bracket	6cm x 1.7cm x 2.5cm	2	

Product assembly

Miren Sideboard 160cm

Step 1



Parts, fittings and tools



Place the Cabinet (1) on a soft surface near to where the cabinet will be used. Mind the doors when turning, as they can open. Locate the legs (2) as shown above using the allen bolts (A) and the allen key (D)

Step 2

Parts, fittings and tools






With 2 people carefully place the sideboard on its feet. Take care when lifting not to damage the legs.

Product assembly

Mirren Sideboard 160cm

Step 3



Parts, fittings and tools



Locate the wall brackets (E) in the slots on the back of the cabinet and fasten to the inside of the cabinet with the small allen bolt (B), and the allen key (D).

Step 4

Parts, fittings and tools



Move the sideboard into its location of intended use next to a wall. Turn the adjustable feet so the sideboard is level (you can use a spirit level to help here).


Product assembly

Mirren Sideboard 160cm

Step 5

Parts, fittings and tools

E



Once the sideboard has been leveled, slide the wall brackets (E) towards the wall. The wall bracket (E) may also require some adjustment to fit correctly depending on any obstructions behind the sideboard such as skirting boards, picture rails etc.

With a pencil lightly and precisely mark the position of the brackets on the wall. Now carefully move the sideboard away from the wall to allow space for drilling.



Step 6

Parts, fittings and tools

B

D

E



Loosen the small allen bolt (B), and remove the wall bracket (E) from the sideboard with the allen key (D).

Product assembly

Mirren Sideboard 160cm

Wall attached item only:

A guide to wall mounting and fixings



A guide to wall mounting and fixings


Serious or fatal crushing injuries can occur from furniture tipping over.

To prevent this furniture from tipping over it must be permanently fixed to the wall.

Wall fixing screws are not included, since different wall materials require different types of screws / fixings. Please ensure you use the correct screws / fixings for your type of walls and seek professional advice if you are not sure.

Failure of the product due to incorrect fixings is the responsibility of the installer.

Important: When drilling into the walls always check that there are no hidden wires or pipes etc.




Types of walls

You can use one of the following types of wall plug if your walls are made of brick, breezeblock, concrete, stone or wood.


1. General purpose wall plug

Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general - purpose wall plugs can be used.




2. Plasterboard wall plug

For use when attaching light loads onto plasterboard partitions.




3. Cavity fixing wall plug

For use with plasterboard partitions or hollow wooden doors.




4. Cavity fixing - heavy duty wall plug

For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.



5. Hammer fixing wall plug

For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.



6. Shield anchor wall plug - heavy loads

For use with heavier loads such as TV and Hi-Fi speakers and satellite dishes etc.



Care and maintenance

Safety: Periodically check all fittings and wall fixings to ensure they have not come loose and retighten as necessary.



Product assembly

Mirren Sideboard 160cm

Step 7

Parts, fittings and tools

E



Reposition the wall bracket between the marks made in step (5) and mark with a pencil where the screw holes are going to be located. Before drilling, ensure the size of holes will be correct to fit the rawl plugs (not included).

Warning: Ensure the area to be drilled is free from hidden electrical wires, water and gas pipes.

Caution: The wall fixings supplied are for solid brick walls only.



Drill the holes according to the marked position. Push the rawl plugs (not included) into position as shown above.

Step 8

Parts, fittings and tools

C

E



Secure the wall brackets (E) to the wall using the washers (C) and screws (not included). Tighten with the screwdriver.



Product assembly

Mirren Sideboard 160cm

Step 9

Parts, fittings and tools


1 B D E



Locate the sideboard so that the wall brackets insert into the slots on the sideboard as shown above. Then open the doors and tighten the small allen bolts (B), to the wall brackets (E) with the allen key (D).

Step 10


Parts, fittings and tools



You can adjust the shelves to your desired height by removing the screws at the bottom of the shelves.

Product assembly

Mirren Sideboard 160cm



Care and maintenance

Wood furniture

Wood displays different grain patterns depending on which way they are cut - for example, the 'medullary ray' which can appear on oak furniture is a mark of good quality timber - these are just characteristics of the natural beauty of the wood. Some furniture is also deliberately aged and rustic.

Wood veneers also allow a distinctive pattern to be created on some surfaces, such as tabletops and drawer fronts by the way slivers are arranged.

All timber and veneer surfaces will change colour and mellow over time. New furniture will initially vary in shade from items that have been previously purchased.

How to care for your wood furniture

Furniture with a hard lacquer, wax polish or painted surface should be dusted with a dry cloth.

Spray polishes are best avoided as they contain silicones which may spoil the furniture's surface when building up over time.

Make sure all surfaces are protected from the heat and liquids by mats and coasters. Wipe up spills immediately and ensure that a mat or pad is placed under paper if you are writing.

Our furniture will endure most temperatures in the home, but it is best to avoid placing furniture next to heat sources such as radiators or fires. Be particularly careful with solid wood as the lack of humidity caused by home heating can cause damage such as warping.

Caution

Please avoid contact with hard, sharp objects. Avoid placing plant pots or vases without waterproof mats to prolong the life of the product.

Please do not sit or lean on this product.

Maximum Load Capacity: 80lbs for the top surface, 22lbs for each shelf.

Retain these instructions for future reference.

Your feedback is very important to us and we would love to hear your comments on you new furniture. Please visit our website to leave a review. Thank you.

Safe Home – Furniture

At Studio Lodon we pride ourselves in developing product that is great quality, offering the best possible value for money.

We also care about your safety, engineering product to minimise any potential risk and providing you with information to enable you to make your home safe and prevent accidents from happening.

Furniture stability

Furniture stability and ‘tipping or overturning’ is of particular concern and it’s important to consider the environment in which your furniture is being placed and who might come in to contact with it. For example small children may be attracted to toys placed out of reach and may use furniture as a ladder to retrieve them. The elderly may also use furniture to pull themselves up from low seating and even pets climbing on furniture could cause furniture to become unstable.

It’s also recommended that heavy items such as TVs are positioned on furniture suitable for the job to prevent any risk of the furniture toppling over.

Other considerations to prevent accidents are how furniture is loaded. Heavier items should be positioned on lower shelves or lower drawers so that the furniture is more stable and less likely to topple.

Wall fixing or attachment devices

We would strongly recommend that all freestanding furniture over 60cm in height is attached to the wall for added safety. This is critical where babies and children have access and there is an increased risk of a toppling incident occurring.

Consider the type of wall that your furniture is to be positioned against when making your purchase and make sure that you use the correct wall fixings referring to the ‘Wall anchoring guide’ which you will find in your product instructions.

If in doubt about which wall fixings to use, or if you’re concerned about your DIY competency seek expert advice from a qualified tradesperson.

Warning label

The following label can be found on own brand products and is affixed permanently. This should remain on the product for the duration of its life additionally offering guidance to customers that purchase the furniture in the second hand market.

